

## Formal notes for Lyra-8 and manual

Underground is underground, music is music, niche is niche but we are forced to put the information in with the applicable EU law if we want to sell our beautiful instruments without problems.

Please read these notes and keep in mind that you should follow them.

Any other action, including the artistic and conscious destruction of instruments or the use of them for any purpose (for example as a bookshelf) takes place at the sole risk, pleasure, blood and tears of the user.

### How the product should be used safely?

1. Please do not open the product! It is prepared by the manufacturer for use and does not require any adjustment in its interior. In case of doubt about the correct operation of the product, please contact the manufacturer.
2. Installation and operation of this product must be carried out by a competent staff only.
3. Before using the product, please read the enclosed operating instructions.
4. Instructions should not be discarded, please keep it for reuse.
5. The product should be used under normal operating conditions. Avoid sunlight, extremes of temperature or humidity, places subject to vibration, magnetic fields, and other electrical devices that might interfere with normal operation of the product.
6. For the product always use the original packaging box for storage or shipping of the product.
7. In the case of lightning, storms, which may damage the product, the product must be disconnected from the power supplying (remove the power supply plug from the socket).
8. The power supply included with the product should be connected to the grid power supply. Use only the supplied power adapter for the product (12 V DC, 300 mA minimum, center polarity "+"). Other AC adapters can have a different polarity or be designed for a different voltage, so their use may be the reason of an electric shock. If the product is not used for a long time, disconnect the AC adapter from the grid.
9. Keep the product clean with a dry cloth. Do not use liquids to clean the product, including solvents that may damage the product, including its electronics, housing, and inscriptions. Before cleaning the product, turn off the power and unplug the AC adapter from the grid connection.
10. Do not hold any liquid at or near the product that could cause it to flood and consequently damage or cause an electric shock. In case of mishandling of the product due to spillage, immediately disconnect the product from the mains supply. If damage is found, the product must be repaired.
11. Suitable cables, including power and signal cables, must be connected to the product when the power is off and the volume is set to the minimum position. This will prevent damage to the amplifier and / or speakers. Do not use the product for a long time at a high volume level what can be a reason of hearing loss or ringing in the ears. You should immediately stop using the product and consult a doctor. The cords and cables should be prevented from entangled. All cords and cables should be out of reach of children of course.
12. Never climb on the top of the product, nor place heavy things on the product on it.
13. The supplier constantly strive to maintain the products at highest professional standard levels. As a result of these efforts, technical specifications and appearance are subject to change without notice. It means that the specifications are correct at the time of publishing or printing, especially the colors of the product may vary from those offered before.